

# Concentration Predictions of Eutectic LiCl-KCl Mixtures Containing Multiple Lanthanides

Devin Rappleye, Michael Simpson

*Department of Metallurgical Engineering  
University of Utah  
135 S 1460 E Rm 412, Salt Lake City, UT 84112*

Sang-Mun Jeong

*Department of Chemical Engineering  
Chungbuk National University  
Cheongju, Chungbuk 361-763, Republic of Korea*

International Pyroprocessing Research Conference  
October 19<sup>th</sup>-23<sup>rd</sup>, 2014  
Idaho Falls, Idaho

# Acknowledgements

- Sean Morrell, Idaho National Laboratory



- Lauryn Hansen & Mario Gonzales, University of Utah




# Online Monitoring

## Electrochemical Methods


### Cyclic Voltammetry

$$i_p = 0.4463A \sqrt{\frac{(nF)^3 D v}{RT}} C$$




### Chronoamperometry

$$i(t) = nFA \sqrt{\frac{D}{\pi t}} C$$




### Chronopotentiometry

$$i(\tau) = \frac{nFA}{2} \sqrt{\frac{D\pi}{\tau}} C$$



# Interference

- Multiple Analytes




Redox Couple	$E^o$ (vs. $\text{Cl}_2/\text{Cl}^-$ )
$\text{Zr}^{2+}/\text{Zr}$	-1.98
$\text{U}^{3+}/\text{U}$	-2.52
$\text{Np}^{3+}/\text{Np}$	-2.67
$\text{Pu}^{3+}/\text{Pu}$	-2.75
$\text{Cm}^{3+}/\text{Cm}$	-2.86
$\text{Am}^{2+}/\text{Am}$	-2.88
$\text{Gd}^{3+}/\text{Gd}$	-2.95
$\text{La}^{3+}/\text{La}$	-3.11

\*Values from Zhang, J. Nucl. Mater. Vol. 447, pp. 271-284

\*Taken from:  
<http://seniordesign.engr.uidaho.edu/2010-2011/inl/Images/Hot%20Cell/MarkIVElectrorefiner.png>

# Interference




# Nuclear Pyrometallurgy Laboratory


- Inert Ar Glovebox
  - $O_2 < 1$  ppm
  - $H_2O < 1$  ppm
- $T = 773$  K
- Alumina Crucible
- WE – 1mm Mo wire
- CE – Gd Rod [6.35 mm x 25 mm]
- RE – 1 wt% AgCl in Pyrex tube
- Chemicals:
  - $GdCl_3$ ,  $LaCl_3$ , Eutectic LiCl-KCl
  - 99.99% Ultra Dry



# GdCl<sub>3</sub> & LaCl<sub>3</sub> Cyclic Voltammetry



# GdCl<sub>3</sub> & LaCl<sub>3</sub> Chronopotentiometry






## $\text{GdCl}_3$ & $\text{LaCl}_3$ Electrochemistry

- Deposited/Reduced separately
- Deposited metals form alloy
- Stripped/Oxidized together
- Significant overlap of reduction current
  - Interference for concentration predictions

**“If you torture the data long enough,  
it will confess”  
– Ronald Coase**

# Concentration Prediction Methods

- Cyclic Voltammetry
  - Separate
    - Peak Height Analysis
  - Together
    - Principle Component Regression (PCR)



# Peak Separation

## Semi-Differentiation



- Better Separation
- More Symmetrical

## Peak Fit



- Bifurcated Gaussian

## Semi-Integration

- Fitted Peaks



# Peak Separation Results




Unknown	#1	#2
Measured (wt%)	1.81	3.64
Predicted (wt%)	2.16	3.63

Unknown	#1	#2
Measured (wt%)	0.97	2.33
Predicted (wt%)	1.02	2.29

# Principle Component Regression (PCR)

- Uses all the data
- Identify main contributors to variance from a training set
  - Principal Components (PCs)
- Training Set
  - Gd = 1.5, 3, 4.5 wt%
  - La = 1, 2, 3 wt%
- Regress the PCs with concentration
- Predict unknown composition




# PCR Results



- Mixed Results:
  - Unknown #1
    - Good Gd agreement
    - Bad La agreement
  - Unknown #2
    - Bad Gd agreement
    - Good La agreement

Unknown		GdCl <sub>3</sub> (wt%)	LaCl <sub>3</sub> (wt%)
#1	Measured	1.68	0.99
	Predicted	1.67	1.60
#2	Measured	3.73	2.49
	Predicted	4.63	2.62

# Peak Height vs. PCR




# Peak Fitting Challenges





# PCR Challenges

- Reducing variations unrelated to concentration:
  - Working electrode surface
  - Reference electrode shift
  - Deposit growth
- Possible solutions:
  - Add analyte to melt
  - Increase scan rate



# Moving Forward

- Generate more uniform data
  - Vary concentrations within same experiment
- Develop better peak fitting criteria
- Other methods:
  - Model Fit
    - ERAD
  - Multiple Electrochemical Methods
    - CV + CA
- Additional multicomponent systems
  - Less interaction
  - Further spaced

“Even if you’re on the right track, you’ll get run over if you just sit there”  
– Will Rogers

